



COBOD CONCRETE PISTON PUMP RECOMMENDED CUSTOMER LOCAL STOCK (ELECTRIC VERSION)

Version 1 - August 2026






Included in this document:

1. SENSORS KIT (BOTH ON EU AND UL VERSION)
2. SAFETY GRID MAGNETIC SENSOR KIT (BOTH ON EU AND UL VERSION)
3. MAIN CONTROL ELECTRICAL BOARD (EU VERSION ONLY)

Disclaimer: These recommendations are based on operating the pump with standard concrete and following proper maintenance and cleaning procedures. The use of experimental cementitious materials, unusual aggregates, or abrasive chemical additives, as well as inadequate maintenance or cleaning practices, may significantly reduce the service life of the components. Extreme weather conditions may reduce the life cycle of the parts and increase maintenance checks. Ideally all customers have Consumables, Wearables and stock parts at all times to prevent down-time in operation. **Please note Consumables and Wearables are NOT covered under warranty.**

Local Stock spare parts: Parts the manufacturer advises keeping in stock so they're on hand when needed, minimizing downtime.

Note: Cells highlighted in yellow indicate items classified as "Show Stoppers": components deemed critical to operation, without which the process cannot proceed.

Number	Location on image	Visual reference	Name	ERP No.	Amount in equipment	Number of operational hours before replacement is recommended
1. SENSORS KIT (BOTH ON EU AND UL VERSION):						
 						
1	11 (Left)		Inductive sensor (stainless steel) ⚠️ !OPERATIONAL SHOWSTOPPER! ⚠️	ADIPP00000005	2	1500 - 2000 Hours
2	47 (Right)		Inductive sensor ⚠️ !OPERATIONAL SHOWSTOPPER! ⚠️	ADIPP00000002	2	1500 - 2000 Hours
2. SAFETY GRID MAGNETIC SENSOR KIT (BOTH ON EU AND UL VERSION):						
						
3	22, 23, 24		Magnetic sensor with support	O00000424	1	800 Hours
3. MAIN CONTROL ELECTRICAL BOARD (EU VERSION ONLY):						
4	-		Main control board ⚠️ !OPERATIONAL SHOWSTOPPER! ⚠️	ADIPP00000110	1	Only when showing signs of damage