


Thank you for choosing COBOD Slice

To set up COBOD Slice and start preparing 3D models for printing with COBOD 3D construction printers, follow the steps outlined on the next page. ➤



COBOD SLICE

This short guide applies to all COBOD Slice users and covers the essential steps for installing and configuring the software. COBOD Slice is compatible with BOD2, BOD3, and BODXL 3D printers and operates independently to streamline the slicing process. Feature availability depends on your license. For details on available features and licensing, contact your regional sales manager or info@cobod.com.





COBOD CONNECT Account Setup




Download and Install COBOD Slice



Activate with Your License Key




Login



Go to <https://connect.cobod.com/> and log in with your COBOD Connect account details.

E-mail & Password



Your email address is your username.

Need Help?



If you don't have an account, please contact your regional sales manager. They can assist you in creating one.


Required: To access and download COBOD Slice, you need a COBOD Connect account.

Required: To access your license key, you need an account on [licenses.cobod.com](https://cobod.users.licensespring.com/licenses.cobod.com)

Your Personal Access

To download and use COBOD Slice, ensure you have a COBOD Connect account. This account is required for accessing the software. If you don't have an account, contact your regional sales manager for assistance. Once logged in, follow the steps below to download and activate the software.

1) Download




Log in to [COBOD Connect](https://connect.cobod.com/)

- Navigate to **Downloads > Software > COBOD Slice**
- The latest version will appear at the top
- Click on it to expand the details
- Scroll down and click on the file to download

Follow the installation wizard to complete setup

2) Launch



- Open COBOD Slice.
- Enter your license key when prompted

Need Help? Contact your regional sales manager for support.

- Go to: <https://cobod.users.licensespring.com/>
- Log in using your email address

Follow the instructions to retrieve your license key and activate COBOD Slice.

This short guide applies to all COBOD Slice users.

For additional support or information, including licensing details and feature overviews, please contact your regional sales manager or mail:

info@cobod.com

COBOD.COM/CONTACT

